

Proxy-Clean® Brand

Triple-C®

Cool Cell Cleaner

Triple-C® Efficiently Removes
Mineral & Scale Build-Up
From Cool Cell Pads

**Equipment Friendly
with Foaming Action**

DIRECTIONS FOR USE:

NORMAL CLEANING of COOL CELL PADS

1. Allow system to operate until pads are wet
2. Add 1 Quart of Triple-C® to the recirculation tank
3. Allow system to circulate for 4-6 hours (*Foaming is Normal*)
4. Turn OFF system & rinse pads with fresh water
(*System can be allowed to sit IDLE overnight & rinsed the next day*)
5. Drain system & refill with fresh water

HEAVY CLEANING of COOL CELL PADS UTILIZING the QWIK-FOAM APPLICATOR

1. Allow system to operate until pads are wet
2. Use Qwik-Foam applicator to foam 1 Quart of Triple-C® directly onto the Cool Cell Pads
3. Allow system to circulate for 6-8 hours (*Foaming is Normal*)
4. Turn OFF system & rinse pads with fresh water
(*System can be allowed to sit IDLE overnight & rinsed the next day*)
5. Drain system & refill with fresh water

Manufactured For:
Proxy-Clean® Products
2020 McKinney Street
Melissa, TX 75454
www.proxyclean.com
FOR INDUSTRIAL USE ONLY

Net Contents 1 US Quart

Proxy-Clean® is a Registered Trademark
Triple-C is a Registered Trademark